


# LP-II User's Guide

## Main Menu

To enter the main menu from the regular weighing mode, press  or .



WEIGHT	UNIT %%	TOTAL PRICE \$
0.00	0.00	0.00

Regular Weighing Mode


## Date & Time

From the Main Menu:


Press  for *Store Settings*

Enter password (default is 001)

Press 

Press  for *Date & Time*

The time is based on the 24 hour format (1:00 pm = 1300).

When finished, press 

Press 

## New PLU's


From the Main Menu:

Press  for *PLU: Program PLUs*.

Press  for *Create PLUs*.

Type in the department number and press .

The scale will always show the lowest available PLU #.

If this number is correct, press . Otherwise, enter a

number between 1 and 999999 and press .

Select PLU type:

(1 = By-Weight • 2 = By-Count • 3 = Non-Food)

Enter the label format number

(See owner's manual for a list of Label Format Numbers)



Enter name


(Please note that there are three lines of 38 characters each in the PLU name. Some label formats may not have space for all three lines. Most formats use two lines of text.)

When finished entering the name, press .

After the *country of origin* field is the *tare weight* field.

To enter a known tare, simply type in the numeric value.

To enter an unknown tare, press  (or ). Place the

container to be tared off on the platter. Press  to

capture the tare. Take the container off of the platter.

Continue entering the PLU information.

When entering the *Sell By* and *Cook by* dates,


remember that the number of days includes

the current day. When entering the ingredients text for

each PLU, use *TEXT 1* for all ingredients data to be


printed on the label. The remaining data to be programmed

is *Nutrition Facts*.

When programming is complete, press .

The scale will go back to *PLU: Create PLU* screen.

At this point, you can program another PLU or

press  to finish.

Please note: You may press  at any point

to save the PLU to go on to the next PLU.


## Store Name

From the Main Menu:

Press  for *Store Settings*

Enter password (default is 001)

Press 



Press  for *Store Name*

Type in the store name

Press 

This is what will print on the label. Please note that there are three lines of 50 characters each in the store name. Some label formats may not have space for all three lines. Most formats use two lines of text

When finished, press 

Press  or  to return to regular weighing mode.

## Departments

From the Main Menu:

Press  for *Store Settings*

Enter password (default is 001)

Press 


Press  for *Department Names*



Type in the Department Number

Press 

Type in the Department Name

Press .

Department Number will go to the next available number. If another Department is required, press .

If not then press  or  to return to regular weighing mode.

# LP-II User's Guide

## Edit PLU's

From the Main Menu:

Press **4** *PLU:Program PLUs*

Enter password (default is 001)

Press **ENTER**

Press **4** for *Edit PLUs*

Type in the Department Number

Press **ENTER**

Type in the PLU Number (1 - 999999)

Press **ENTER**

Select PLU type:

(1 = By-Weight • 2 = By-Count • 3 = Non-Food)

Follow the instructions for *New PLUs* editing information where necessary.

## Price Changes

From the Main Menu:

Press **4** *PLU:Program PLUs*

Enter password (default is 001)

Press **ENTER**

Press **1** for *Change PLU Prices*

Type in the Department Number

Press **ENTER**

Type in the PLU Number (1 - 999999)

Press **ENTER**

The current unit price, sale weight, and sale price will appear. After you make any changes, press **ENTER**. The scale will then return to Department #.

When finished, press **ESC** twice.

## Global Label Format

From the Main Menu:

Press **9** for *Global Settings*

Enter password (default is 001)

Press **ENTER**

Press **1** for *Label Format*

Enter the Label Format Number (See owner's manual for Label Format Numbers)

Press **ENTER**

Press **Y** if you wish to use this Label Format for ALL PLUs, or **N** if you want to apply this Label Format to this PLU only.

Press **ENTER**

Press **ESC**

## Label Feed Adjustments

From the Main Menu:

Press **7** *Store Settings*

Enter password (default is 001)

Press **ENTER**

Press **7** for *Adjust Feed Length*

The adjustment number can be between 0 and 200 (Default is 110). To move the print on the label up, increase the number. To move the print on the label down, decrease the number. For every 8 counts, the label print moves 1 mm.

Enter the new value.

Press **SAVE**

Press **ESC**